


# Procedure Card for IDenta Marijuana/Hashish Identification

## INSTRUCTIONS

A. Remove sampler from the top Identa test unit.



B. Press sampler's adhesive tip onto suspected substance, Collecting as much substance as possible.



C. Return sampler to the test unit and press firmly to lock. **Warning: Do not continue to the next step until sampler is completely locked into place.**



D. **With thumb and forefinger**, firmly press Chamber 1 until ampoule breaks.



E. Gently shake test unit for 1 minute. (No color will appear at this point)



F. **With thumb and forefinger**, firmly press Chamber 2 until ampoule breaks.



G. Gently shake test unit for a few seconds.



H. A blue-violet color in the window indicates the presence of Marijuana or Hashish.



I. If a blue-violet color develops, proceed with step K to confirm presence of Marijuana/Hashish.

\* Note: If the quality of drug is poor, color development may be more gradual - over 1 minute. Please allow sufficient time for blue-violet (or purple) color development.

J. If a blue-violet color does NOT develop, neither Marijuana nor Hashish is present and confirmation is not required.



## Confirmation

K. **With thumb and forefinger**, firmly press Chamber 3 until ampoule breaks.



L. Gently shake test unit for a few seconds. Hold steady, allowing layers to separate. Allow window contents to settle. Two liquid layers will form.



M. If the lower liquid layer turns a blue violet color, the presence of Marijuana/Hashish is confirmed. Color may darken with time.



**Important: As a precaution, eye protection should be worn, In case of eye or skin contact rinse immediately with water.**